

# DEKS

**Installation Guide :**

**Dektites Rubber & Silicone**

*Follow  
Us On*



### Installation Guide for Metal roof Dektites

1. Trim rubber boot to suit pipe size, ensure surface is clean and dry before application.



2. Slide down pipe using water as a lubricant, if needed.



3. Apply sealant by turning back flexible flange.



4. Press base to the roof profile firmly. Smooth out any creases.



5. Fasten using self-sealing screws.



Retrofit application (for DC combos):

1. Trim rubber boot to suit pipe size, then cut seam. Ensure surface is clean and dry before application.

2. With seam in downstream position wrap boot around pipe and engage 1st double clip at top of seam using multigrips, then, engage remaining clips working down from top of tuber boot to base.

3. Apply sealant to outside of seam closure and to underside of Dektite.

4. Fasten flashing base by placing a screws either side of seam first then secure rest of base.

5. Press base to the roof profile firmly. Smooth out any awkward creases.

6. Fasten using self-sealing screws rest of the flashing base.

# DEKS

*Follow  
Us On*

