

## FOR TILE AND SLATE ROOFS

**IMPORTANT: MAKE SURE THE TILE/SLATE, PIPE AND CABLE ARE CLEAN AND FREE FROM BURRS AND SHARP EDGES BEFORE INSTALLATION.**



### STEP - 1



Cut the Dektite® DFE200RES cone and/or cable inlets to the relevant size using snips.

### STEP - 2



Pass the pipe and/or cable through the Dektite® using water as lubricant.

### STEP - 3



Apply the DEKS “Dektite Flashing Adhesive” to the underside of the flashing.

### STEP - 4



Press flashing on the contour of the tile roof.

### STEP - 5



Apply additional sealant around the edge of the flashing.

## FOR METAL ROOFS

**IMPORTANT: MAKE SURE THE METAL ROOF, PIPE AND CABLE ARE CLEAN AND FREE FROM BURRS AND SHARP EDGES BEFORE INSTALLATION.**



STEP - 1



Cut the Dektite® DFE200RES cone and/or cable inlets to the relevant size using snips.

STEP - 2



Pass the pipe and/or cable through the Dektite® using water as lubricant.

STEP - 3



Apply the DEKS “Dektite Flashing Adhesive” to the underside of the flashing.

STEP - 4



Press flashing on the contour of the tile roof.

STEP - 5



Fasten flashing to metal roof using self-drilling fasteners.